

KIT # VER - 09
 for SINGLE SLIDE
 landing door
 Made by DOVER or TURNBULL
 with integral hangers

| Item | Part No. | Description | Q'ty req'd |
|------|---|---|------------|
| 1 | VER - T - D | Top Retainer | 2 |
| 2 | VER - B or VER - B - M or VER - B - D | Bottom Retainer - if door is 1" thick Bottom Retainer - if door is 1 1/4" thick Bottom Retainer - if door is 1 5/8" thick | 1 |
| 3 | TEKS - 2 | Screw 10 - 24 x 3/4 TEKS - 2 or equiv. hexagon washer hd, self tap, self drill | 15 |

Tools Req'd : Electric screwdriver with clutch driven 5/16 hex. socket.
 Clutch set at 30 - 40 inch- pounds torque.
 5/16 & 1/2 wrench for adjustment.

INSTALLATION :

With door closed position top retainers (Item 1) according to dimensions on the drawing.
 Install retainers using supplied hardware, check that retainers will not scrape the door hanger
 when the door is opening or closing.

With door closed position bottom retainer (Item 2) as shown on the drawing.
 Install retainer using one screw in the slotted hole, check that retainer will not scrape the sill
 when door is opening or closing.
 Readjust when necessary, install remaining screws.

