

KIT # VER - 19
for TWO SPEED
landing door
Made by DAHLSTROM
- with integral hangers

Item	Part No.	Description	Q'ty req'd
1	VER - T - R	Top Retainer	2
2	VER - B - W	Bottom Retainer	2
3	TEKS - 2	Screw 10 - 24 x 3/4 TEKS - 2 or equiv. hexagon washer hd, self tap, self drill	12
4		CTSK screws	5
5		Shim (Use where required)	2

INSTALLATION :

With door closed position top retainers (Item 1) according to dimensions on the drawing.
Install retainers using supplied hardware, check that retainers will not scrape the door hanger
when the door is opening or closing.

With door closed position bottom retainer (Item 2) as shown on the drawing.
Install retainer using one screw in the slotted hole, check that retainer will not scrape the sill
when door is opening or closing.

Readjust when necessary, install remaining screws.

