

KIT # VER - R10
for SINGLE SLIDE
landing door
Made by DAHLSTROM
with integral OTIS hangers

Item	Part No.	Description	Q'ty req'd
1	V R 7	Top Retainer - angle	2
2	V R 10	Top Retainer	2
3	VER - B - W	Bottom Retainer - if door is 1" thick	1
4	TEKS - 2	Screw 1/4 - 20 x 3/4 TEKS - 2 or equiv. hexagon washer hd, self tap, self drill	10
5	TEKS - 2	Screw 10 - 24 x 3/4 TEKS - 2 or equiv. hexagon washer hd, self tap, self drill	5

Tools Req'd : Electric screwdriver with clutch driven 5/16 hex. socket.

Clutch set at 30 - 40 inch- pounds torque.

5/16 & 1/2 wrench for adjustment.

INSTALLATION :

With door closed position top retainers according to dimensions on the drawing.

Install retainers using supplied hardware, check that retainers will not scrape the door hanger when the door is opening or closing.

With door closed position bottom retainer as shown on the drawing.

Install retainer using one screw in the slotted hole, check that retainer will not scrape the sill when door is opening or closing.

Readjust when necessary, install remaining screws.

